

Introduction to Optoelectronic Device Simulation by Joachim Piprek


Outline:

1. Introduction: VCSEL Example
2. Electron Energy Bands
3. Drift-Diffusion Model
4. Thermal Model
5. Gain/Absorption Model
6. Optical Model

Main source:


Semiconductor Optoelectronic Devices: Introduction to Physics and Simulation
by J. Piprek, Academic Press, San Diego, 2003

Horizontal and Vertical Cavity Lasers




2

Example: 1.55μm Vertical-Cavity Surface-Emitting Laser (VCSEL)



3

Optoelectronic Device Modeling




4

Electron Energy Bands


- based on Schrödinger Equation $H\Psi=E\Psi$
 - Ψ – electron wave function
 - H – Hamiltonian
 - E – electron energy
- material parameters:
 - lattice constants
 - electron effective mass
 - Luttinger parameters
 - energy gaps, offsets
 - elastic stiffness constants
 - deformation potentials
- output: $E(x,y,z, k_x, k_y, k_z)$
 - x,y,z = position in space
 - $k_x, k_y, k_z \propto$ momentum in space

5

Energy Bands




Fermi Energy Position



© 2003 Academic Press, used by permission


6

Electron Distribution $n(E)$



$$f(E) = \frac{1}{1 + \exp\left[\frac{E - E_F}{k_B T}\right]}$$


Fermi vs. Boltzmann



© 2003 Academic Press, Reprinted by permission

7


Conduction and Valence Bands: $E(k)$



© 2003 Academic Press, Reprinted by permission

8

Influence of Strain (GaAs)



© 2003 Academic Press, Reprinted by permission

9

Drift-Diffusion Model

- based on Semiconductor Transport Equations
- input: geometry, materials, doping
- material parameters:
 - carrier mobility
 - carrier generation & recombination
 - dielectric constant
 - energy band offsets
- output: density of electrons (n) and holes (p)
- current density distribution (j)
- current vs. voltage (IV)

10

Drift-Diffusion Equations

$$\nabla \epsilon \nabla \phi = -e(n - p + C)$$

$$\nabla \vec{J}_n = e(R - G)$$

$$\nabla \vec{J}_p = -e(R - G)$$

$$\vec{J}_n = -en\mu_n \nabla \phi + eD_n \nabla n$$

$$\vec{J}_p = -en\mu_p \nabla \phi - eD_p \nabla p$$


$$R = R_{SRH} + R_{Auger} + R_{spont} + R_{stim}(g, \vec{E})$$

$$G = G_{abs}(\alpha, \vec{E})$$

electron and hole carrier densities $n(\vec{r}), p(\vec{r})$
 electron and hole current densities $\vec{J}_n(\vec{r}), \vec{J}_p(\vec{r})$
 recombination and generation rates $R(\vec{r}), G(\vec{r})$
 electrostatic potential $\phi(\vec{r})$
 optical field strength $\vec{E}(\vec{r})$
 optical gain and absorption $g(\vec{r}), \alpha(\vec{r})$
 electron charge e
 doping density $C(\vec{r})$
 dielectric constant $\epsilon(\vec{r})$
 carrier mobilities $\mu_n(\vec{r}), \mu_p(\vec{r})$ ($D = \frac{kT}{e} \mu$)

11


p-n-Junction



© 2003 Academic Press, Reprinted by permission

12

Mobility of Electrons and Holes




$$\mu(T) = \mu_0 \left(\frac{T}{300 \text{ K}} \right)^a$$

$$\mu(N_{\text{dop}}) = \mu_{\text{dop}} + \frac{\mu_0 - \mu_{\text{dop}}}{1 + (N_{\text{dop}}/N_{\text{ref}})}$$

13

Recombination Mechanisms




© 2003 Academic Press, Reprinted by permission

Recombination Parameters


spontaneous emission

$$R_{\text{spont}} = B (np - n_0 p_0)$$



Auger recombination


$$R_{\text{Aug}} = (nC_n + pC_p)(np - n_0 p_0)$$



© 2003 Academic Press, Reprinted by permission

15


Multi-Quantum Well Active Region



© 2003 Academic Press, Reprinted by permission


16

Semiconductor Heterojunctions



© 2003 Academic Press, Reprinted by permission


Energy Band Gap vs. Composition for III-V Compounds



© 2003 Academic Press, Reprinted by permission

18

Example: VCSEL



© 2003 Academic Press, Reprinted by permission

19

Defects at fused InP/GaAs interface

Energy Band Diagram

InP/GaAs band offset

$$\Delta E_c = 0.12 \text{ eV}$$


$$\Delta E_v = 0.05 \text{ eV}$$

donor-type interface traps

density 10^{13} cm^{-2}

energy $0.7 \text{ eV} + E_v$


cross section 10^{-17} cm^2



npnp Shockley diode switch (thyristor)


20

VCSEL Threshold Voltage



21

InP/GaAs Trap Effect on 2D Current Distribution



22

Thermal Model

- based on Heat Flux Equation
- input: geometry, materials
heat source distribution $P(r,z)$
Joule heat
nonradiative recombination
absorption etc.
- material parameters (steady state)
thermal conductivity $k(T,r,z)$
- output: temperature distribution $T(r,z)$
thermal resistance

23

Heat Flux Equation (r,z)

$$\frac{\partial}{\partial r} \kappa_r \frac{\partial T}{\partial r} + \frac{1}{r} \kappa_r \frac{\partial T}{\partial r} + \frac{\partial}{\partial z} \kappa_z \frac{\partial T}{\partial z} = -\frac{\partial P}{\partial V}(r, z)$$

(T - temperature , $\partial P / \partial V$ - heat power density)


with anisotropic thermal conductivity in bottom DBR

$$\kappa_r = \frac{d_1 \kappa_1 + d_2 \kappa_2}{d_1 + d_2} \text{ and } \kappa_z = \frac{d_1 + d_2}{d_1 / \kappa_1 + d_2 / \kappa_2}$$

(κ_1, κ_2 - bulk material thermal conductivities
 d_1, d_2 - DBR layer thicknesses > phonon mean free path).

24



InP Alloy Thermal Conductivity



© 2003 Academic Press, Reprinted by permission

25



Thin Layer Thermal Conductivity



26

VCSEL Self-Heating

- two problems:
- heat flux
 - heat power




© 2003 Academic Press, Reprinted by permission


27

VCSEL Heat Flux


Geometry



Temperature



Heat Flux




28

Gain/Absorption Model

- based on (quantum well) energy band structure
- input: geometry, materials
- material parameters:
 - band structure parameters (incl. strain)
 - transition matrix element
 - dielectric constant
- output: band-to-band gain/absorption function $g(T, \lambda, N)$

29

Quantum Well Energy Bands



© 2003 Academic Press, Reprinted by permission

30

basic gain calculation

$$g = C_g M^2 D_r (f_c - f_v)$$

C_g pre-factor
 M transition matrix element
 D_r reduced density of states
 $f_c - f_v$ inversion factor
 < 0 absorption
 > 0 gain


spontaneous emission

$$r_{sp} = C_{sp} M^2 D_r D_{opt} f_c (1 - f_v)$$

C_{sp} pre-factor
 D_{opt} photon density of states

31


Spontaneous Emission and Gain



© 2003 Academic Press, Reprinted by permission

32


Quantum Well Gain Spectrum with Energy Broadening



© 2003 Academic Press, Reprinted by permission

33


Gain / Absorption vs. Carrier Density [10^{18}cm^{-3}]



34

Temperature Effects on VCSEL Gain

- emission wavelength, $N=3 \times 10^{18}\text{cm}^{-3}$



=> gain reduction triggers carrier density increase at higher temperatures

35

Optical Model

- based on Maxwell Equations
- input: geometry, materials
- material parameters: refractive index $n(T,z)$
absorption coefficient $\alpha(T,z)$
- output: standing wave (mode)
emission wavelength
threshold gain
optical quantum efficiency

36

Maxwell Equations

$$\nabla \times \vec{E} = -\mu_{opt} \frac{\partial \vec{H}}{\partial t}$$

$$\nabla \times \vec{H} = \varepsilon_{opt} \frac{\partial \vec{E}}{\partial t}$$

$$\nabla(\varepsilon_{opt} \vec{E}) = 0$$

$$\nabla(\mu_{opt} \vec{H}) = 0$$

electric fields strength $\vec{E}(\vec{r})$
 magnetic fields strength $\vec{H}(\vec{r})$
 dielectric constant (optical frequency) $\varepsilon_{opt}(\vec{r})$
 magnetic permeability (optical frequency) $\mu_{opt}(\vec{r})$

37

Dielectric Constant


$$\varepsilon = \varepsilon_1 + i \varepsilon_2$$

$$\varepsilon_1 = n^2 - k^2$$

$$\varepsilon_2 = 2 n k$$

$$k = \lambda \alpha / 4 \pi$$

n – refractive index
 α – absorption const.
 λ – wavelength



© 2003 Academic Press, Reprinted by permission

38

Helmholtz Equations

within uniform, isotropic,
 and passive layers

$$\begin{aligned} \nabla^2 \vec{E} + k_o^2 \varepsilon \vec{E} &= 0 \\ \nabla^2 \vec{H} + k_o^2 \varepsilon \vec{H} &= 0 \end{aligned}$$


reduced scalar waveguide equations for harmonic wave in z-direction

$$\frac{\partial^2 \Phi}{\partial x^2} + \frac{\partial^2 \Phi}{\partial y^2} + (k^2 - \beta^2) \Phi = 0$$

k – wave vector, β – propagation constant

39

VCSEL: Effective Index Method



scalar wave equation:

$$\frac{1}{r} \frac{\partial}{\partial r} \left(r \frac{\partial W}{\partial r} \right) + \frac{1}{r^2} \frac{\partial^2 W}{\partial \theta^2} + \frac{\partial^2 W}{\partial z_r^2} + k^2 W = 0$$

solution:

$$W = W_r(r) \exp(-jk_z z_r)$$

$W_r(r)$ from Bessel equation of order m :


$$\frac{d^2 W_r}{dr^2} + \frac{1}{r} \frac{dW_r}{dr} + \left(k^2 - k_z^2 - \frac{m^2}{r^2} \right) W_r = 0$$




40

VCSEL: Transversal Optical Intensity

Bessel Functions




Near Field Measurement



© 2003 Academic Press, Reprinted by permission

41

VCSEL: Vertical Optical Intensity



© 2003 Academic Press, Reprinted by permission




42

VCSEL: 2D Mode Matching

980nm Vertical-Cavity Laser

top: GaAs/Al_xO (2.8μm)

bottom: GaAs/AlGaAs




[Noble et al., IEEE J. Quantum Electronics 34, 1890 (1998)]

43

Conclusion

1. self-consistent combination of relevant models
2. careful adjustment of material parameters



questions: piprek@ieee.org

44